

To protect the privacy of
customers or suppliers of
Salamander Jewelry.
We erased their address from
this document.

Document No. : TR-EO-001031016

Date : 3/10/2016

Page : 2 / 4

PRODUCT : ORDER NO. 2161163

SAMPLE SLIP PARAMETER

00:05:13	058,70	000kPa	
23:55:13	058,70	000kPa	
23:45:13	058,70	000kPa	
23:35:13	058,50	000kPa	
23:25:13	058,60	000kPa	
23:15:13	058,60	000kPa	
23:05:13	058,70	001kPa	
22:55:13	058,70	000kPa	
22:45:13	058,70	057kPa	
22:35:13	058,60	058kPa	
22:25:13	058,60	063kPa	
22:15:13	058,60	066kPa	
22:05:13	058,50	077kPa	
21:55:13	058,50	115kPa	
21:45:13	058,40	213kPa	
21:35:13	058,30	311kPa	
21:25:13	058,10	311kPa	
STERI 21:18:41	058,30	311kPa	
21:15:13	058,30	-029kPa	
ADD ED 21:11:16	058,20	-067kPa	
21:05:13	058,20	-010kPa	
HUMID 21:01:14	057,90	-088kPa	
PRETT 20:55:13	057,50	000kPa	
PREHEAT 20:14:41	052,60	-001kPa	
STATE	TIME	TEMP	PRE

RUN COUNT : 0903

EO PRE :060kPa VENT TIME:04H 00M

STERI TEMP: 056,00 STERI TIME:07H 00M

PRO TYP 20:14:41 052,60 -001kPa

START TIME: 2016-10-01 20:14:33

EXHAUST:04H 00MIN TOTAL :12H 09MIN
PRETT :01H 04MIN STERI :07H 00MIN
ACTUAL TIME

08:23:54 STERILIZATION SUCCESS

END 08:23:43	059,10	-004kPa
08:23:43	059,10	-004kPa
04:27:37	058,40	-015kPa
EXHAUST 04:17:43	058,30	000kPa
04:15:13	058,40	000kPa
04:05:13	058,30	000kPa
03:55:13	058,30	000kPa
03:45:13	058,40	000kPa
03:35:13	058,40	000kPa
03:25:13	058,30	001kPa
03:15:13	058,30	000kPa
03:05:13	058,30	-001kPa
02:55:10	058,40	000kPa
02:45:13	058,30	000kPa
02:35:13	058,40	000kPa
02:25:13	058,60	000kPa
02:15:13	058,60	000kPa
02:05:13	058,30	000kPa
01:55:13	058,30	000kPa
01:45:13	058,30	001kPa
01:35:13	058,30	000kPa
01:25:13	058,40	000kPa
01:15:13	058,40	000kPa
01:05:13	058,30	001kPa
00:55:13	058,30	000kPa
00:45:13	058,30	000kPa
00:35:13	058,30	000kPa
00:25:13	058,70	000kPa
00:15:13	058,70	000kPa