


Report Test

To protect the privacy of customers or suppliers of Salamander Jewelry.
We erased their address from this document.

LOT No : 0333/2022
Date : 5 January 2022

Determination of Sterilization Operation Specification

Item Detail	Specification	Setting	Result
Chamber Setting Temperature	40.0-55.5 °C	45.0 °C	
Vacuum pressure	40-60 kPa	60 kPa	
Vacuum Time	50-60 min	60 min	
Humidification			
Humidity	50.0-90.0%	20.2 %	
Sterilization			
Sterilization Temperature	40.0-55.5 °C	43.5 °C	
Gas Injection			
Final pressure	0-10 kPa	4 kPa	
Final temperature of vaporizer	40.0-55.5 °C	44.8 °C	
Exposure			
Temperature at start point of Exposure time period	40.0-55.5 °C	43.3 °C	
Temperature at finish point of Exposure time period	40.0-55.5 °C	46.0 °C	
Exposure Time	120-240 min	180 min	
Exhaust			
Exhaust Time	60-80 min	75 min	
First Vacuum pressure	0-2 kPa	1.5 kPa	
Second Vacuum pressure	0-2 kPa	1.5 kPa	
Third Vacuum pressure	0-2 kPa	1.5 kPa	
Fourth Vacuum pressure	0-2 kPa	1.5 kPa	
Fifth Vacuum pressure	0-2 kPa	1.5 kPa	
Storage			
Storage Time	≥ 48 hour	≥ 48 hour	
Chemical Test			
EO sterilization temperature 40-55°C, Time Sterilization by EO 3hours	Blue	Red	Pass
Biological Test			
EZ Test Biological Indicator	Green	Green	Pass


 (.....)
 Mr. Jutha Liamukda
 Research and Development Engineer
 Salamander Jewelry Co., Ltd.



SALAMANDER
jewelry

Salamander Jewelry Co., Ltd.

128/1 Moo 7, Soi Wat Nakhon Chuenchum, Phutthamonthon Sai 4 Rd.
Tambon Krathumlom, Amphur Sampran, Nakhon Pathom 73220, Thailand.
Tel: 66-2814-4455 | Fax: 66-2-814-3300 | Email: info@body-piercing.com
Website: www.body-piercing.com

Sterilization:
Temperature: 44.7°C
Humidity: 20.2RH
Pressures: -4.1KPa
Sterilization time: 3Hour
Air replace rounds: 5
round time: 15min(s)
2021-11-12 15:20

Add E0 gas
Temperature: 44.6°C
Humidity: 20.2RH
Pressures: -4.0KPa
Sterilization time: 3Hour
Air replace rounds: 5
round time: 15min(s)
2021-11-12 15:20

Evacuation
Temperature: 44.7°C
Humidity: 20.1RH
Pressures: -0.0KPa
Sterilization time: 3Hour
Air replace rounds: 5
round time: 15min(s)
2021-11-12 15:10

Keeping Temp
Temperature: 44.9°C
Humidity: 20.1RH
Pressures: -1.5KPa
Sterilization time: 3Hour
Air replace rounds: 5
round time: 15min(s)
2021-11-12 14:10

Keep pressure qualified
Temperature: 43.9°C
Humidity: 20.1RH
Pressures: -56.8KPa
Sterilization time: 3Hour
Air replace rounds: 5
round time: 15min(s)
2021-11-12 14:8

Evacuation
Temperature: 42.5°C
Humidity: 20.1RH
Pressures: -3.0KPa
Sterilization time: 3Hour
Air replace rounds: 5
round time: 15min(s)
2021-11-12 13:56

Heating-up:
Temperature: 22.8°C
Humidity: 20.1RH
Pressures: -3.0KPa
Sterilization time: 3Hour
Air replace rounds: 5
round time: 15min(s)
2021-11-12 13:29

Setting:
Temperature: 45.0°C
Humidity: 55.0RH
Pressures: -60.0KPa
Sterilization time: 3Hour
Air replace rounds: 5
round time: 15min(s)
2021-11-12 13:28

END

Air replacement:
Temperature: 45.5°C
Humidity: 20.2RH
Pressures: -1.5KPa
Sterilization time: 0Hour
Air replace rounds: 1
round time: 0min(s)
2021-11-12 19:46

Air replacement:
Temperature: 45.9°C
Humidity: 20.2RH
Pressures: -1.5KPa
Sterilization time: 0Hour
Air replace rounds: 2
round time: 0min(s)
2021-11-12 19:26

Air replacement:
Temperature: 45.6°C
Humidity: 20.2RH
Pressures: -1.5KPa
Sterilization time: 0Hour
Air replace rounds: 3
round time: 0min(s)
2021-11-12 19:6

Air replacement:
Temperature: 45.0°C
Humidity: 20.2RH
Pressures: -1.5KPa
Sterilization time: 0Hour
Air replace rounds: 4
round time: 0min(s)
2021-11-12 18:46

Air replacement:
Temperature: 44.9°C
Humidity: 20.2RH
Pressures: -1.5KPa
Sterilization time: 0Hour
Air replace rounds: 5
round time: 15min(s)
2021-11-12 18:26

Sterilization:
Temperature: 44.9°C
Humidity: 20.2RH
Pressures: -0.0KPa
Sterilization time: 0Hour
Air replace rounds: 5
round time: 15min(s)
2021-11-12 18:21

Sterilization:
Temperature: 45.3°C
Humidity: 20.2RH
Pressures: -3.9KPa
Sterilization time: 3Hour
Air replace rounds: 5
round time: 15min(s)
2021-11-12 15:22



SALAMANDER
jewelry

Salamander Jewelry Co., Ltd.

128/1 Moo 7, Soi Wat Nakhon Chuenchum, Phutthamonthon Sai 4 Rd.
Tambon Krathumlom, Amphur Sampran, Nakhon Pathom 73220, Thailand.

Tel: 66-2814-4455 | Fax: 66-2-814-3300 | Email: info@body-piercing.com

Website: www.body-piercing.com

LINE	Code	Description	LOT	Color	BOX	TOTAL
		2380240				
14	TDI-Z-TMBL-1.2-8.0-3-HP	STERILE TITANIUM MICRO BARBELL FOR TDI	LOT-0333			100
18	TDI-Z-TMCB-1.2-10.0-3	STERILE TITANIUM MICRO CIRCULAR BARBELL FOR TDI	LOT-0333			300
		2381078				
11	PT-Z-TMBN-1.2-10.0-3	STERILE TITANIUM MICRO CURVED BARBELL FOR PTIT ROC	LOT-0333			349
12	PT-Z-TMBN-1.2-8.0-3	STERILE TITANIUM MICRO CURVED BARBELL FOR PTIT ROC				282
15	PT-Z-TMLB-1.2-10.0-3	STERILE TITANIUM MICRO LABRET FOR PTIT ROC				227
17	PT-Z-TMLB-1.2-9.0-3	STERILE TITANIUM MICRO LABRET FOR PTIT ROC				190
24	PT-Z-TMLB-1.2-8.0-3	STERILE TITANIUM MICRO LABRET FOR PTIT ROC				1294
		2379982				
11	PT-Z-TMBL-1.2-8.0-3-HP	STERILE TITANIUM MICRO BARBELL FOR PTIT ROC	LOT-0333			292
14	PT-Z-TMLB-1.2-10.0-3	STERILE TITANIUM MICRO LABRET FOR PTIT ROC				285
15	PT-Z-TMLB-1.2-6.0-3	STERILE TITANIUM MICRO LABRET FOR PTIT ROC				215
		2378411				
8	PT-Z-TMBN-1.2-10.0-3	STERILE TITANIUM MICRO CURVED BARBELL FOR PTIT ROC	LOT-0333			220
		2362330				
25	TDI-Z-TINMBL-1.2-8.0-3	STERILE TITANIUM INTERNALLY THREADED MICRO BARBELL FOR TDI	LOT-0333			100
		2382381				
2	PT-Z-XBL-1.1-6.20.0-5-CL	STERILE BIOFLEX BARBELL WITH STEEL BALLS FOR PTIT ROC	LOT-0333			61
		160433				
5	Z-COBC-1.0-8.0	STERILE SURGICAL STEEL SEAMLESS RING	LOT-0333			4
6	Z-COBC-1.2-10.0	STERILE SURGICAL STEEL SEAMLESS RING				4
		160454				
8	Z-PNV-CRE	STERILE DISPOSAL ROUND CLAMPS	LOT-0333			1
		153996				
2	Z-RGBLDS-1.6-14.0-5-CR	STERILE ROSE GOLD PVD COATED SURGICAL STEEL DOUBLE SIDE HIGH END CRYSTALS JEWEL NIPPLE BARBELL	LOT-0333			6
		159440				
4	Z-BNDJ-1.6-8.0-4/8-CR	STERILE SURGICAL STEEL DOUBLE HIGH END CRYSTALS JEWEL NAVEL BANANA	LOT-0333			4
		160361				
6	Z-MCB-1.2-8.0-3	STERILE SURGICAL STEEL MICRO CIRCULAR BARBELL	LOT-0333			100
		160453				
10	Z-BL-1.6-19.0-5	STERILE SURGICAL STEEL BARBELL	LOT-0333			1
		160514				
2	Z-MBLSC104-1.2-8.0-3	STERILE SURGICAL STEEL TRAGUS MICRO BARBELL - WING	LOT-0333			1
3	Z-BNDJ-1.6-10.0-5/8-LS	STERILE SURGICAL STEEL DOUBLE HIGH END CRYSTALS JEWEL NAVEL BANANA	LOT-0333			1
		160505				
1	Z-FPL-1.2-6.0-8	STERILE SURGICAL STEEL FAKE PLUG	LOT-0333			2
		160532				
1	Z-XONR-0.8-7.0-2-BK	STERILE BIOFLEX OPEN NOSE RING	LOT-0333			2
		160565				
1	Z-BL-1.6-10.0-4	STERILE SURGICAL STEEL BARBELL	LOT-0333			4
2	Z-BL-1.6-12.0-4	STERILE SURGICAL STEEL BARBELL	LOT-0333			4
3	Z-BL-1.6-14.0-4	STERILE SURGICAL STEEL BARBELL	LOT-0333			4
4	Z-BL-1.6-16.0-3	STERILE SURGICAL STEEL BARBELL	LOT-0333			4
5	Z-BL-1.6-20.0-5	STERILE SURGICAL STEEL BARBELL	LOT-0333			8
6	Z-BL-1.6-42.0-5	STERILE SURGICAL STEEL BARBELL	LOT-0333			1
7	Z-BL-1.6-44.0-5	STERILE SURGICAL STEEL BARBELL	LOT-0333			1
8	Z-BNDJ-1.6-12.0-5/8-AB	STERILE SURGICAL STEEL DOUBLE HIGH END CRYSTALS JEWEL NAVEL BANANA	LOT-0333			3
9	Z-BNDJ-1.6-12.0-5/8-BZ	STERILE SURGICAL STEEL DOUBLE HIGH END CRYSTALS JEWEL NAVEL BANANA	LOT-0333			3
10	Z-BNDJ-1.6-12.0-5/8-RO	STERILE SURGICAL STEEL DOUBLE HIGH END CRYSTALS JEWEL NAVEL BANANA	LOT-0333			3
11	Z-JNG-0.8-6.5-2.35-CR	STERILE SURGICAL STEEL HIGH END CRYSTAL JEWEL CURVED NOSE STUD	LOT-0333			6
13	Z-JNG-0.8-6.5-2.35-AM	STERILE SURGICAL STEEL HIGH END CRYSTAL JEWEL CURVED NOSE STUD	LOT-0333			2
14	Z-JNG-0.8-6.5-2.35-AQ	STERILE SURGICAL STEEL HIGH END CRYSTAL JEWEL CURVED NOSE STUD	LOT-0333			2
15	Z-JNG-0.8-6.5-2.35-LS	STERILE SURGICAL STEEL HIGH END CRYSTAL JEWEL CURVED NOSE STUD	LOT-0333			2
16	Z-MCB-1.2-10.0-3	STERILE SURGICAL STEEL MICRO CIRCULAR BARBELL	LOT-0333			2
18	Z-SCES430-3	STERILE SURGICAL STEEL EAR STUDS PAIR - BALL 3MM	LOT-0333			4
21	Z-XBNNJ-1.1-6-12.0-5/8-CL-CR	BIOFLEX JEWEL NAVEL BANANA WITH SURGICAL STEEL BALL	LOT-0333			3
		TOTAL				4097

