

Report Test

To protect the privacy of customers or suppliers of Salamander Jewelry.
We erased their address from this document.

LOT No: 1037/2025
Date: 20 August 2025

Determination of Sterilization Operation Specification

| Item Detail | Specification | Setting | Result |
|---|---------------|-----------|--------|
| Chamber Setting Temperature | 40.0-55.5 °C | 45.0 °C | |
| Vacuum pressure | 40-60 kPa | 60 kPa | |
| Vacuum Time | 50-60 min | 60 min | |
| Humidification | | | |
| Humidity | 50.0-90.0% | 20.2 % | |
| Sterilization | | | |
| Sterilization Temperature | 40.0-55.5 °C | 43.5 °C | |
| Gas Injection | | | |
| Final pressure | 0-10 kPa | 4 kPa | |
| Final temperature of vaporizer | 40.0-55.5 °C | 44.8 °C | |
| Exposure | | | |
| Temperature at start point of Exposure time period | 40.0-55.5 °C | 43.3 °C | |
| Temperature at finish point of Exposure time period | 40.0-55.5 °C | 46.0 °C | |
| Exposure Time | 120-240 min | 180 min | |
| Exhaust | | | |
| Exhaust Time | 60-80 min | 75 min | |
| First Vacuum pressure | 0-2 kPa | 1.5 kPa | |
| Second Vacuum pressure | 0-2 kPa | 1.5 kPa | |
| Third Vacuum pressure | 0-2 kPa | 1.5 kPa | |
| Fourth Vacuum pressure | 0-2 kPa | 1.5 kPa | |
| Fifth Vacuum pressure | 0-2 kPa | 1.5 kPa | |
| Storage | | | |
| Storage Time | ≥ 48 hour | ≥ 48 hour | |
| Chemical Test | | | |
| EO sterilization temperature 40-55°C, Time Sterilization by EO 3hours | Blue | Red | Pass |
| Biological Test | | | |
| EZ Test Biological Indicator | Green | Green | Pass |

Preawplern Wongphutorn
(.....)
Miss. Preawplern Wongphutorn
Order Assembly and Sterilization Manager
Salamander Jewelry Co., Ltd.